

## INSTALLATION INSTRUCTIONS

### Tools Needed

- Screwdriver • Drill & Bits • 2 Molly Bolts, Toggle Bolts, or Large Wood Screws (depending on wall) • Level •
- Plumbers Basin Wrench to secure Faucet (Optional) • Wrench • Pencil • Tape Measure • Plumbers Putty •

**Be sure to re-inforce wall before installation. We recommend a 2"x12" securely fastened to wall studs at desired height for your installation.**

### Wall Hung Installation

1. Determine the height you want. Place basin against the wall. Use a level to make sure both sides are level.
2. Position each metal mounting bracket against the underside rear of basin and against the wall. Mark the location of mounting bracket holes on the wall.
3. Remove the basin from the wall. **Wall should be reinforced before continuing.**
4. Start to drill hole **through 2"x12" re-inforced wall** for molly bolts or toggle bolts. If drill bit hits a stud, mount bracket and bolts using large wood screws.
5. If molly bolts are used, install and expand the bolt holder and then mount brackets.
6. If toggle bolts are used, make holes large enough to accept collapsible wing nut bolts and then mount bracket.
7. Before replacing basin, it would be convenient at this point to mount the faucet according to the manufacturer's instructions.
8. Hold basin on wall brackets and ensure that it is level.
9. Connect all supply tubes to the faucet. Connect trap and drain assembly as described by the manufacturer.



### 3/4 Pedestal Installation

1. Place plastic legs into slots on inside of pedestal (side with multiple holes against ped). Mark position of hole into wall.
2. Drill hole in **2"x12" re-inforced wall** and insert plastic plugs.
3. Gold screw and washer are mounted into the plug through the plastic leg.
4. Place cover against plastic legs, place plastic bushing over chrome screw and screw into plastic leg.
5. While still holding cover; place decorative chrome cover over chrome screw. Repeat on other side.

### Above Counter Installation

1. Use level to ensure that the counter top is level. Next, carefully position the basin in the desired location. Ensure you have provided proper clearance under the counter top for the faucet, supply lines, drain assembly and the structural parts of the cabinet. Mark desired drain and faucet location on counter top with pencil.
2. Drill a 3-1/2" (89 mm) hole at drain location. Drill a 1 3/8" (35 mm) hole at faucet mount location.
3. Position basin on counter, centering it above the drain hole. Place clear silicone bead around perimeter of basin where basin meets counter.
4. Pre-assemble P-trap drain connections in accordance with manufacturer's instructions. Check that pop-up drain opens and closes properly when drain control is operated.
5. Connect supply lines to shutoff valves and tighten nuts securely.
6. Install faucet and drain in accordance with manufacturer's instructions. Hand tighten drain and add one quarter turn to allow the sink to expand and contract with changing water and room temperatures. If drain leaks, add another quarter turn. Repeat this process until leak stops. Do not over tighten to prevent stress cracks. Turn on water supply valves and water-test installation.