
INSTALLATION INSTRUCTIONS

Parts Included

- 1 Curved Rod • 1 Extender Rod •
- 2 #340 Flanges • Mounting Hardware •

Tools Needed

- Small Blade Screwdriver • Phillips Screwdriver • Level • Drill with 1/8" Bit •
- Pipe Cutter / Hacksaw (Optional) •



1. Measure wall opening.
2. Place the two ends of the rod together, if it came as two pieces.
3. Measure rod. Rod is adjustable by moving the extender rod in or out.
4. When desired size is achieved, slide flanges on each end and install rod in opening.
**** Do Not use set screws yet. ****
5. After rod is secured to walls, use a level to make sure rod is level side to side and front to back. Now install set screws. A 1/8" pilot hole is recommended for optimum strength.