

---

## INSTALLATION INSTRUCTIONS

### Parts Included

- 2 Spigot Faucets • 2 Large Locknuts • 2 Screws (for handles) • 2 Handles •

### Tools Needed

- Adjustable Wrench • Slip Joint Pliers • Pipe Putty or Teflon Pipe Tape •

**NOTE: Handles are identified HOT and COLD.  
The hot handle must be to the left and cold to the right.**



1. Align the spigot nipples with the holes in the sink.
2. Apply teflon tape or putty to both ends of the hot and cold supply nipples. On the underside of the sink, thread the large locknuts onto the other ends of the nipples and secure the spigots to the sink. Tighten with a wrench or pliers.
3. Remove screws from valve stems. Place hot and cold handles onto stems. Then replace screws and secure.
4. Connect the water supply nipples to the water supply tubes.

**NOTE: Please seek professional help if you have copper plumbing in your home.**

### Cleaning Instructions

Wipe this whole set off with warm water and a soft cloth. DO NOT use soaps, cleansers, or brass cleaners as they will disintegrate the protective lacquer coating and leave the brass exposed causing it to tarnish.