

INSTALLATION INSTRUCTIONS

Parts Included

- 1 Hook Shower Arm • 1 Wall Flange •

Tools Needed

- Wrench • Teflon Tape •
- Silicone Caulk •



1. Remove old showerhead by unwinding showerhead joint counter-clockwise. Use wrench if necessary. Use cloth or pad on wrench to protect finish.
2. Remove old shower arm and flange by unwinding counter-clockwise.
3. Wrap teflon tape clockwise around both ends of new shower arm thread. Slip flange onto shower arm and screw shower arm clockwise into in-wall water outlet. Tighten connection and adjust arm to appropriate position.
4. Install showerhead onto arm by turning showerhead joint clockwise onto shower arm pipe thread.
5. Turn on water to test. Tighten connections further if necessary. If no problem with testing, apply silicone caulk on flange and affix flange onto wall.

Cleaning Instructions

To maintain and protect the finish, clean with soft damp cloth only.